



STRAIGHT MODULES 93-1200



053-L93090	STRAIGHT MODULE 93-1200-090 025-025
053-L93190	STRAIGHT MODULE 93-1200-190 061-061
053-L93290	STRAIGHT MODULE 93-1200-290 097-097
053-L93390	STRAIGHT MODULE 93-1200-390 100-133
053-L93490	STRAIGHT MODULE 93-1200-490 099-169
053-L93590	STRAIGHT MODULE 93-1200-590 098-172
053-L93690	STRAIGHT MODULE 93-1200-690 097-171
053-L93790	STRAIGHT MODULE 93-1200-790 095-170
053-L93890	STRAIGHT MODULE 93-1200-890 094-168
053-L93990	STRAIGHT MODULE 93-1200-990 092-167

USAGE NOTES	max distributed load: 97 kg with gearbox size 40 97 kg with gearbox size 50 load limits of the entire conveyor, not of the single module
	L3 = belt width - 10 L4 = belt width + 80

USAGE

