



STRAIGHT MODULES 93-1950



053-T93090	STRAIGHT MODULE 93-1950-090 025-025
053-T93190	STRAIGHT MODULE 93-1950-190 061-061
053-T93290	STRAIGHT MODULE 93-1950-290 097-097
053-T93390	STRAIGHT MODULE 93-1950-390 100-133
053-T93490	STRAIGHT MODULE 93-1950-490 099-169
053-T93590	STRAIGHT MODULE 93-1950-590 098-172
053-T93690	STRAIGHT MODULE 93-1950-690 097-171
053-T93790	STRAIGHT MODULE 93-1950-790 095-170
053-T93890	STRAIGHT MODULE 93-1950-890 094-168
053-T93990	STRAIGHT MODULE 93-1950-990 092-167

USAGE NOTES

max distributed load:
 97 kg with gearbox size 40
 97 kg with gearbox size 50
 load limits of the entire conveyor, not of the single module

L3 = belt width - 10
 L4 = belt width + 80

USAGE

